


PHOTO ASSEMBLY GUIDE: WINGS



CONTENTS

SECTION	DATE	DESCRIPTION
6-W-0	12/23/03	Table of Contents
6-W-1	12/09/03	Flaps
6-W-2	12/23/03	Ailerons
6-W-3	09/01	Outboard Wing Spar Assembly
6-W-5	12/09/03	Spar Tip/ Nose Rib
6-W-6	08/30/01	Rear Ribs/ Aileron Bellcrank
6-W-7	12/09/03	Rear Channel/ Right Wing Skeleton
6-W-8A	11/17/03	Leveling the wing skeleton, Rear skins
6-W-6B	11/17/03	Leading Edge Skin
6-W-9	12/09/03	Tie Down Ring/ Access Cover/ Wing Tip/ Pitot Tube
6-W-10	01/23/03	Aileron Control/ Bellcrank/ Deflection/ Stops
6-K-1	01/23/03	Leading Edge Wing Tanks/ Fuel Sender
6-LLO-1	12/09/03	Landing Light Option

NOTICE: This photo assembly guide has been written and published strictly for informational purposes to aid in the construction of the ZODIAC kit aircraft. It has been prepared as a guide to facilitate the assembly of ZODIAC kit aircraft. It is published to be used with the ZODIAC CH 601 Drawings & Manuals. The photos are used for general identification only, and are not to be taken to represent technical drawings. You should not consider the educational material in the manual to be the practice of general aviation nor is it intended for this guide to be a complete account of sheet metal aircraft technology: it is limited to the scope of the assembly of ZODIAC kit aircraft. This guide is not intended to replace, substitute or supersede any technical information contained in the ZODIAC Drawings and Manuals, Newsletter Updates, or any Federal Aviation Administration regulations. Information contained in this photo assembly guide has been obtained by Zenith Aircraft Company from sources believed to be reliable, however, we cannot guarantee the accuracy or completeness of any information published herein and we shall not be responsible for any errors, omissions, or potential damages arising out of use of this information.